USE 1 3/8" OR 1 7/16" MINI CLOCK INSERT CHECK YOUR CLOCKS SPECIFICATIONS FOR THE EXACT SIZE OF MOUNTING OPENING. MAKE UPRIGHT AND BASE FROM 3/8" STOCK OR PLYWOOD. DOTTED LINE INDICATES PLACEMENT POSITION OF UPRIGHT ON BASE. ATTACH WITH GLUE AND /OR SMALL SCREWS. QUEE72E0/1508 7

BASE - SIDE VIEW

BASE - 3/8" X 1 3	/4" X 7 1/2"	