



These pattern are designed to be used with the 15/16" micro mini clock inserts. Please check your clock's specifications for the exact size of the mounting hole and drill accordingly.

All parts are cut from 1/4" stock or plywood. The use of the mounting tabs is optional and may be eliminated if desired. Simply cut the bottoms straight then glue to base. The tabs do offer a more secure attachment without need for screws or nails.

ARPOP











